


## **EP1000**

Embedded Systems 2 Programming



## **Arduino System**

- Programs written for the Arduino system are text files called sketches (extension .ino)
- The programming language used is based on <u>Processing</u>, which is loosely based on the C++ syntax.



A simple and easy introduction to Programming Arduino. Available in the SP Library



#### Sketches

- All Arduino sketches have 2 functions:
  - setup()
     code is executed only once
     used for initialisation and
     setup of I/O
  - loop()
     code is executed
     continuously
     application code is placed
     here

```
Basic Sketch
void setup()
   // code is executed only once
void loop()
    // code is run continously
```



#### **Variables**

- Variables are memory set aside to hold changing data.
- Variables use different amounts of memory depending on the data type used.
- Common data types are
  - char 8-bit
  - int 16-bit
  - float 32-bit
  - String stores a sequence of characters
- We use identifiers (names) to name the variable and locate it.
- Use conversion functions to convert between them

#### **Data Types**

- array
- bool
- boolean
- byte
- char
- double
- float
- int
- <u>long</u>
- short
- size\_t
- string
- String()
- unsigned char
- unsigned int
- unsigned long
- void
- word



### **Operators**

#### **Arithmetic Operators**

- <u>% (remainder)</u>
- <u>\* (multiplication)</u>
- + (addition)
- <u>- (subtraction)</u>
- / (division)
- <u>= (assignment</u> <u>operator)</u>

#### **Boolean Operators**

- ! (logical not)
- <u>&& (logical and)</u>
- | (logical or)

#### Bitwise Operators

- <u>& (bitwise and)</u>
- << (bitshift left)</pre>
- >> (bitshift right)
- ^ (bitwise xor)
- <u>| (bitwise or)</u>
- <u>~ (bitwise not)</u>

#### Compound Operators

- <u>%= (compound remainder)</u>
- <u>&= (compound bitwise and)</u>
- \*= (compound multiplication)
- ++ (increment)
- += (compound addition)
- <u>-- (decrement)</u>
- <u>-= (compound subtraction)</u>
- /= (compound division)
- ^= (compound bitwise xor)
- <u>|= (compound bitwise or)</u>

Use the **KISS** principle!

Operators work only with **Similar** data types Use conversion functions to help.



#### Boolean

- Boolean variables have only 2 values: True/False
- Boolean expressions have only 2 results: True/False
- Comparison operators give a Boolean result
- Boolean operators work only with Booleans

#### Comparison Operators

- != (not equal to)
- < (less than)</li>
- <= (less than or equal to)</li>
- <u>== (equal to)</u>
- <u>> (greater than)</u>
- >= (greater than or equal to)

#### **Boolean Operators**

- ! (logical not)
- && (logical and)
- | (logical or)

Used in Conditionals, Loops



## Conditional: if ... else

- Control Structure which checks the condition expression and if true executes the following code block.
- Condition Expression is a Boolean expression.
- When used with the else, control transfers to the else block.
- Can have nested or have multiples else-if conditionals for more granular control.

```
if (temperature < 30)
{
    // increase heat
    ...
}

else

// maintain
```



### Conditional: <a href="mailto:switch...case">switch...</a> case

- Control Structure which checks the value in Switch (preferably ordinal) and transfers control to the matching Case code block.
- Each case code block must be terminated with a **break**.
- Each case must match exactly.
- Control is transferred to the default code block (if any) if there is no match.

```
die = roll();
                    // rolls a die
switch(die){
    case 6:
        // scores and rolls again
        score = score + 6 + roll();
        break:
    case 1:
        // forfeits turn (no score)
        break:
    case 4:
        // deducts points
        score = score - 4;
        break:
    default:
        // all other values
        score = score + die;
        break:
```



# Loop: for

- Structure of for
  - Initialization
  - Conditional expression
  - Increment
- Used when we know exactly the number of times we wish to loop.

Loops a **fixed** number of times



# Loop: while

- Tests conditional expression, if true the code block is executed.
- Indefinte loop, code block is executed zero, once or many times.
- If the condition results always in True, we have an endless loop.

```
// execute code when switch is pressed
while (ispressed(key1))

{
    // key is pressed
    count = count + 1
    ...
}

// what will be the default
// condition state?
```

Loops a  $0, 1 \dots n$  number of times



## Loop: do ... while

- Executes the code block before testing the conditional expression.
- If conditional expression is true the code block is repeated.
- Indefinte loop, code block is executed once or many times.
- If the condition results always in True, we have an endless loop.

```
// execute code when switch is pressed
do

// control light intensity
value = value - 1;
light(value);
// check brightness
lightIntensity = measureBrightness();

while ( lightIntensity > 25 )

while ( lightIntensity > 25 )

// what happens if the lightIntensity
// was originally 10 before the loop
// was entered
// 18
```

Loops a 1 ... 

∩ number of times



### Control: break

- When used in a loop, break exits the loop, control transfers to next statement after loop.
- break is also used to transfer control out of a matching case in a switch statement.
- Control: <u>continue</u> ignores the remaining statements and transfers control to the loop condition. (not commonly used)

// read the sensor



#### **Functions**

- A function is identified using ()
- A function is a block of code that can accept parameters.
- Executes the code when called, returns a single value as it's name.
- return is used to return the value in the indicated data type.

```
/* function
    name: cube
    parameters: int value
    returns: int
int cube(int value){
    result = value * value;
    return result
// execution
myAnswer = cube(4);
int data = 6;
yourAnswer = cube(data);
```



#### Class

- A user-defined data type that is used to create objects.
- An object has
  - attributes (constants, variables)
  - methods (functions)
- An object's attributes and methods are accessed using the dot (.) operator
- Classes are predominantly used in code libraries

Classes should be identified using a starting uppercase character e.g. Serial



### Directive: #define

- #define is a compiler directive and not a code statement.
- Does not end with a semicolon
- Used to name a constant and assign the value
- const is the preferred method of defining constants

```
// Replace all occurences of LED_RED
// with the value 7
#define LED_RED 7
// alternative
// const is a keyword
const int LED_RED = 7;
```

Constants should be identified using uppercase



### Directive: #include

- **#include** is a compiler directive and not a code statement.
- Does not end with a semi-colon
- Instructs the compiler to read and insert code from the target file

```
// include the system library
// (found in a folder on the
// path)
#include <wire.h>
// include the local library
// found in the local folder
#include "mystepper.h"
// libraries are external code
// to help in your projects
```

- < file > indicates system library, found along the library path
- " file " indicates local file in same folder



## **EP1000**

Embedded Systems 2
Programming

End